

Add new equipment to Amazon Alexa

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Before new system devices can be added to Amazon Alexa, it is required to add an Alarm.com powered light or thermostat to your Alarm.com account. See the installation instructions that came with the device or contact your dealer for support for more information about how to add an Alarm.com powered light or thermostat to your Alarm.com account.

Platform	Mobile App
Content type	How-to / Configuration
Source last updated	2026-01-07

Procedure

To add a device to the Smart Home skill

1. Open the Amazon Alexa app.
2. Tap [Amazon Devices].
3. Tap [Add].
4. Tap Add Device.

5. Tap Other.
6. Tap Z-Wave.
7. Tap Discover Devices.

Alternatively, ask Alexa by saying, "Alexa, discover my devices."

You should now be able to control your newly named device. If commands are not triggering a device action, check the Your Devices section of the Alexa app to confirm the device is listed.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Home_Automation/Amazon_Alexa_Smart_Home_Skill/Add_new_equipment_to_Amazon_Alexa

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:29:55 UTC by Jerdenn Calag

Updated 2026-09-01 00:29:55 UTC by Jerdenn Calag