

Change parent meter settings for an energy monitoring device

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Select a parent meter a device is included in the measurements from one of your other metering devices.

Platform	Customer Website
Content type	How-to / Configuration
Source last updated	2025-06-04

Procedure

To change parent meter settings

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Activity.
3. Click Energy Usage.
4. Click Settings & Bill Information.

5. Click Manage Energy Devices.
6. Click the energy monitoring device to be edited.

Using the Parent Meter dropdown menu, select the parent device.

1. Click Save.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Energy_Monitoring/Energy_Monitoring_Settings/Change_parent_meter_settings_for_an_energy_monitoring_device

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:29:54 UTC by Jerdenn Calag

Updated 2026-09-01 00:29:54 UTC by Jerdenn Calag