

Change SmartAway thermostat schedule settings

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

A SmartAway thermostat schedule can change a thermostat's scheduled setpoint based on system activity.

Platform	Customer Website
Content type	How-to / Configuration
Source last updated	2025-06-04

Procedure


Step-by-step guide: Screenshots and videos are placed with the instruction they illustrate.

A SmartAway thermostat schedule can change a thermostat's scheduled setpoint based on system activity. This setting changes the default schedule if the security system is set to Armed Away, or all selected Geo-Devices have left the specified Geo-Fence.

To change SmartAway thermostat schedule settings using the GoSafer Security customer portal (powered by Alarm.com):

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Automation.
3. Click Schedules.
4. Click  on the thermostat schedule to be edited.
5. Click Smart Away.
6. Click the toggle switch to enable or disable the SmartAway thermostat schedule.
7. Click to select the SmartAway options to apply to the thermostat schedule:
 - **System is Armed Away** to only apply the SmartAway settings when the system is in Armed Away. If the panel has multiple partitions, the Smart Away thermostat schedule will be based on the arming status of partition 1.
 - **All geo-devices are outside Geo-Fence** to use the dropdown menu to specify which Geo-Fence will trigger the SmartAway thermostat schedule. For more information, see [Add a new Geo-Device](#) and [What is a Geo-Fence?](#).
8. Click Save Schedule.

The following image is an example of a SmartAway thermostat schedule enabled for when the System is Armed Away, and when the Geo-Devices leave the My Business Geo-Fence.



Thermostat Smart Away

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Home_Automation/Thermostats/Change_SmartAway_thermostat_schedule_settings

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:29:59 UTC by Jerdenn Calag

Updated 2026-09-01 16:40:46 UTC by Jerdenn Calag