

Create a new group thermostat schedule

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Group thermostat schedules allow you to manage thermostats across locations at once.

Platform	Customer Website
Content type	How-to / Configuration
Source last updated	2025-06-04

Procedure

To create a new group thermostat schedule using the GoSafer Security customer portal (powered by Alarm.com)

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Select the desired group from the locations dropdown menu.
3. Click Settings.
4. Click Thermostat Schedules.

5. Click Create New Template.

In the Schedule Name field, enter the desired name for the schedule.

1. Click Heat for a heat schedule or Cool for cool schedule.

Make the desired changes to the thermostat template.

In Location Selection, click to select which locations the template will apply to.

Note: If desired, click Apply this schedule by default to any locations added to the group to any location added to the group.

1. Click Save.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Commercial/Multi-Location_Management/Create_a_new_group_thermostat_schedule

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:29:52 UTC by Jerdenn Calag

Updated 2026-09-01 00:29:52 UTC by Jerdenn Calag