

Create an event-triggered water valve automation rule

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Event Triggered Water Valve rules allow you to automate a Z-wave Water Valve to open or close based on security panel or sensor activity status.

Platform	Customer Website
Content type	How-to / Configuration
Source last updated	2025-06-04

Procedure

To create an event triggered water valve automation rule using the GoSafer Security customer portal (powered by Alarm.com):

Important: When selecting Open as the action to be performed for this rule, the rule will still run in the event of a water shut-off event. This may result in water damage to your home. Please consider this carefully before creating a rule that may involve opening a water valve.

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Automation.
3. Click Add New Rule.
4. Click Event-triggered Rule.

In the Name of rule field, enter the desired rule for the name.

In Automate My, click to select Water Valves.

In When this event occurs, click to select the device that will trigger the Water Valve rule and use the dropdown menus to specify the conditions of the action.

In the Perform this action, use the dropdown menu to specify what the water valve will do when triggered and select a time constraint.

In Select Devices, click to select the water valves that will follow the rule.

In During these time frames, click to select when the rule will be active.

1. Select At All Times to have the rule be carried out at any time of day.
2. Select Only during the following times to choose specific days and times that selected devices are automated by the rule.
3. Verify the rule is configured with the correct settings.
4. Click Save.

To edit an event-triggered water valve automation rule using the GoSafer Security customer portal (powered by Alarm.com):

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Automation.
3. Click [Edit] for the automation rule to be edited.
4. Update the event-triggered water valve automation rule as desired.
5. Verify the rule is configured with the correct settings.
6. Click Save.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original

Alarm.com

reference:

https://answers.alarm.com/Customer/Website_and_App/Home_Automation/Rules/Create_an_event-

[triggered water valve automation rule](#)

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:29:58 UTC by Jerdenn Calag

Updated 2026-09-01 00:29:58 UTC by Jerdenn Calag