

Enable Smart Arming

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

For residential customers, the Smart Arming feature automatically arms the customer's system Arm Stay when they go to bed and Disarm it when they wake up. Smart Arming can be activated at a set time or when sensors detect activity. Smart Arming ensures that the system is secure every night while preventing false alarms. Use-Case Example: A family with a regular nighttime routine schedules Smart Arming to arm the panel at 10:00 PM each night. Because they have small children who may wake early and let the dog out, they auto-disarm when activity is detected between 6:00 AM and 9:00 AM.

Platform	App + Web
Content type	How-to / Configuration
Source last updated	2026-01-27

Procedure

Step-by-step guide: Screenshots and videos are placed with the instruction they illustrate.

For residential customers, the Smart Arming feature automatically arms the customer's system Arm Stay when they go to bed and Disarm it when they wake up. Smart Arming can be activated at a set time or when sensors detect activity. Smart Arming ensures that the system is secure every night while preventing false alarms.

Use-Case Example: A family with a regular nighttime routine schedules Smart Arming to arm the panel at 10:00 PM each night. Because they have small children who may wake early and let the dog out, they auto-disarm when activity is detected between 6:00 AM and 9:00 AM.

System considerations

- Not all panels are compatible with Smart Arming. Contact your service provider for more information about if your panel is compatible.
- Smart Arming will not activate if a system is in Arm Away
- Smart Arming is only available for security systems with one partition
- Sensor-based Arm Stay uses contact and motion sensors to detect activity; users select which sensors to include
- Sensor-based Disarm uses motion sensors only so someone breaking in can not disarm the panel; users select which sensors to include
- Smart Arming schedules that overlap may cause unexpected behavior. It is not recommended to set up overlapping schedules.

Note: Motion sensors with PIR cameras cannot be selected with Sensor-based Arm Stay or Sensor-based Disarm.

Enable Smart Arming

Smart Arming can be configured using the Alarm.com app or GoSafer Security customer portal (powered by Alarm.com).

Important: To manage the Smart Arming rule, the customer login must have *Master Control*, *Full Control*, or *Custom* with *Remote Arming* selected. Additionally, *Limited Device Access* with *Remote Panel Control* and *Read Only* logins are able to view existing Smart Arming settings, but not manage them. For more information about customer permissions, see [Manage login permissions for secondary logins](#).

To enable Smart Arming using the Alarm.com app: **Icon Chevron Up**

Important: Managing this feature on the Alarm.com app requires app version iOS 4.21.14+ and Android 4.21.12+. For custom schedules for each day of the week, iOS 5.13 and Android 5.10+ Alarm.com app version is required.

1. Log in to the Alarm.com app.
2. On the *Security System* card, tap **Smart Arming** for Smart Arming. Tap **Smart Arming**.
3. Tap **+** to create a Smart Arming schedule, or **Edit** on an existing schedule to configure it.
4. In *Select Smart Arming Action*, tap to select either **Wake Up** for disarming or **Goodnight** for arming stay.
5. In *Name Schedule*, enter a name for the schedule.
6. In *Select Schedule Type*, tap either:
 - **Specified Time** to run the schedule at a specific time. If this is selected:
 1. In *Configure Schedule*, use the dropdown menus to select the *Days* and *Starting at* time for this rule to run.
 - Or, if available, **Activity Detected** to run the schedule based on compatible sensor activity. If this is selected:
 - For the *Wake Up* schedule, this option is available if the customer has motion sensors in compatible groups to disarm when activity is detected between specific times for selected sensors included in the

rule.

1. Use the dropdown menus to select the *Days*, *Starting at* time, *Ending at* time, and *Inactivity Period* for this rule to run.
2. In *Select Sensor(s)*, tap to select the sensors used to detect activity for this rule to activate.
3. Additional considerations:

- This schedule only activates when the panel is armed stay.
- When *Disarm at X:XX even if no activity is detected* is selected, the panel disarms at the end of the selected time frame if no motion is detected during the selected time period.
- This rule is designed to disarm once during the selected time period. If the panel has disarmed once due to motion, it will not disarm again at the end of the selected time period.

Example: A user sets the Wake Up rule to disarm the panel due to no activity. The Wake Up rule is triggered to disarm the panel. Within the time frame, the user arms the panel remotely or locally. The Wake Up rule will no longer disarm the panel until the following day.

- For the *Goodnight* schedule, this option is available if the customer has motion/contact sensors in compatible groups to arm stay between specific times when no activity has been detected for a specified duration for selected sensors included in the rule.

1. Use the dropdown menus to select the *Days*, *Starting at* time, *Ending at* time, and *Inactivity Period* for this rule to run.
2. In *Select Sensor(s)*, tap to select the sensors used to detect activity for this rule to activate.
3. Additional considerations:
 - This rule can arm the panel multiple times in the selected time period.

Example: A user sets the Goodnight rule to arm stay after 30 minutes of inactivity. During the time frame, the Goodnight rule triggers to arm stay the panel and the user disarms the panel remotely or locally. Once the inactivity time period is reached again, the rule will trigger the panel to arm stay again.

7. Tap **Save**.

Smart Arming Schedule App
Smart Arming Schedule App

To enable Smart Arming using the GoSafer Security customer portal (powered by Alarm.com): **Icn Chevron Up**

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).

2. On the *Security System* card, click **Smart Arming**.

Note: Smart Arming can also be accessed from the *Automation* page.

3. Click **+ Schedule** to create a Smart Arming schedule, or **Edit** on an existing schedule to configure it.

4. In *Select Smart Arming Action*, click to select either **Wake Up** for disarming or **Goodnight** for arming stay.

5. In *Name Schedule*, enter a name for the schedule.

6. In *Select Schedule Type*, click either:

- **Specified Time** to run the schedule at a specific time. If this is selected:

1. In *Configure Schedule*, use the dropdown menus to select the *Days* and *Starting at* time for this rule to be active.

- Or, if available, **Activity Detected** to run the schedule based on compatible sensor activity. If this is selected:

- For the *Wake Up* schedule, this option is available if the customer has motion sensors in compatible groups to disarm when activity is detected between specific times for selected sensors included in the rule.

1. Use the dropdown menus to select the *Days*, *Starting at* time, *Ending at* time, and *Inactivity Period* for this rule to activate.

2. In *Select Sensor(s)*, click to select the sensors used to detect activity for this rule to activate.

3. Additional considerations:

- This schedule only activates when the panel is armed stay.

- When *Disarm at X:XX even if no activity is detected* is selected, the panel disarms at the end of the selected time frame if no motion is detected during the selected time period.
- This rule is designed to disarm once during the selected time period. If the panel has disarmed once due to motion, it will not disarm again at the end of the selected time period.

Example: A user sets the Wake Up rule to disarm the panel due to no activity. The Wake Up rule is triggered to disarm the panel. Within the time frame, the user arms the panel remotely or locally. The Wake Up rule will no longer disarm the panel until the following day.

- For the *Goodnight* schedule, this option is available if the customer has motion/contact sensors in compatible groups to arm stay between specific times when no activity has been detected for a specified duration for selected sensors included in the rule.
 1. Use the dropdown menus to select the *Days*, *Starting at time*, *Ending at time*, and *Inactivity Period* for this rule to activate.
 2. In *Select Sensor(s)*, click to select the sensors used to detect activity for this rule to activate.
 3. Additional considerations:
 - This rule can arm the panel multiple times in the selected time period.

Example: A user sets the Goodnight rule to arm stay after 30 minutes of inactivity. During the time frame, the Goodnight rule triggers to arm stay the panel and the user disarms the panel remotely or locally. Once the inactivity time period is reached again, the rule will trigger the panel to arm stay again.

7. Click **Save**.

Smart Arming Schedule Web
Smart Arming Schedule Web

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/System_Management/System_Usage/Enable_Smart_Arming

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:06 UTC by Jerdenn Calag

Updated 2026-09-01 16:40:50 UTC by Jerdenn Calag