

# Enable/disable a thermostat Fire Safety rule

## GoSafer Security Knowledge Base

*This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.*

## Overview

To prevent the circulation of smoke and poisonous gas and potential HVAC system damage, a Thermostat Fire Safety rule automatically turns off the HVAC system if a fire or carbon monoxide alarm is ...

|                            |                        |
|----------------------------|------------------------|
| <b>Platform</b>            | Customer Website       |
| <b>Content type</b>        | How-to / Configuration |
| <b>Source last updated</b> | 2025-06-04             |

## Procedure

To enable or disable a thermostat Fire Safety rule using the GoSafer Security customer portal (powered by Alarm.com)

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Automation.
3. Click the toggle switch to enable or disable the Fire Safety rule for the thermostat.

Note: If the thermostat is shut off using the Fire Safety rule, it will not be turned back on automatically after the smoke, fire, or CO alarm clears. The thermostat will need to be manually adjusted back to the desired mode.

# Source and support

For GoSafer Security assistance, visit [gosaferssecurity.com](https://gosaferssecurity.com).

Original Alarm.com reference:  
[https://answers.alarm.com/Customer/Website\\_and\\_App/Home\\_Automation/Thermostats/Enable\\_disable\\_a\\_thermostat\\_Fire\\_Safety\\_rule](https://answers.alarm.com/Customer/Website_and_App/Home_Automation/Thermostats/Enable_disable_a_thermostat_Fire_Safety_rule)

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

---

Revision #1

Created 2026-09-01 00:30:00 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:01 UTC by Jerdenn Calag