

How can I reorganize the video devices on the website and app?

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Alarm.com video devices are listed in alphabetical order by name by default, but users can customize which cameras appear on the Live Video page of the GoSafer Security customer portal.

Platform	Customer Website
Content type	How-to / Configuration
Source last updated	2026-03-24

Procedure

Alarm.com video devices are automatically organized by default in alphabetical order by name, but it is possible to customize which video cameras appear on the Live Video page on the GoSafer Security customer portal (powered by Alarm.com).

For more information about reorganizing video devices, see [Create/edit a camera group](#).

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Video/Live_Video/How_can_I_reorganize_the_video_devices_on_the_website_and_app

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:13 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:13 UTC by Jerdenn Calag