

Set/edit an energy usage goal

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Set energy usage goals for each monitoring device.

Platform	Customer Website
Content type	How-to / Configuration
Source last updated	2025-06-04

Procedure

To set an energy usage goal using the GoSafer Security customer portal (powered by Alarm.com)

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Activity.
3. Click Energy Usage.
4. Click Goals.

Using the Device dropdown menu, select a monitoring device.

In Projected Usage, drag [Set Goal] horizontally to lower or raise the goal budget.

1. Click Save.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Energy_Monitoring/Energy_Monitoring_Usage/Set-edit_an_energy_usage_goal

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:29:54 UTC by Jerdenn Calag

Updated 2026-09-01 00:29:54 UTC by Jerdenn Calag