

Smart Home Skill - Disable Alarm.com in Amazon Alexa

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

There are two ways to disable the Alarm.com Smart Home skill in the Amazon Alexa app.

Platform	Mobile App
Content type	How-to / Configuration
Source last updated	2026-01-07

Procedure

To disable the skill in Alarm.com Smart Home

1. Open the Amazon Alexa app.
2. Tap [Alexa Icon].
3. Tap Skills & Games.

In the search field, enter Alarm.com, then tap Search.

1. Tap Alarm.com Smart Home.

2. Tap Disable Skill.
3. Tap Disable Skill again in the pop-up window.

The Alarm.com Smart Home skill is disabled and does not appear under the Your Smart Home Skills header.

To disable the skill in Your Skills

1. Open the Amazon Alexa app.
2. Tap [Alexa Icon].
3. Tap Skills & Games.

Flick to the bottom, then tap Your Skills.

In Your Skills, tap Alarm.com Smart Home.

1. Tap Disable Skill.
2. Tap Disable in the pop-up window. The Alarm.com Smart Home skill will be disabled and will no longer appear in your list of skills.

Note: Removing the skill from your Amazon Alexa account does not remove the devices listed under All Devices in the [Amazon Devices] section of the app. To remove the devices, see Remove equipment from Amazon Alexa.

Source and support

For GoSafer Security assistance, visit gosafersupport.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Home_Automation/Amazon_Alexa_Smart_Home_Skill/Smart_Home_Skill_Disable_Alarm.com_in_Amazon_Alexa

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

