

What is a Geo-Fence?

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

A Geo-Fence is a circular area defined by the user. This area is used as a reference to determine if a Geo-Device (e.g., a mobile device associated with the account) is inside or outside this area. Based on this, it is possible to create automation rules, reminders, and notifications. For example, a thermostat can be set to specific temperatures based on whether the Geo-Device is inside or outside the radius of the Geo-Fence. [Geo Fence]

Platform	General / Device
Content type	How-to / Configuration
Source last updated	2023-10-31

Procedure

Step-by-step guide: Screenshots and videos are placed with the instruction they illustrate.

A Geo-Fence is a virtual geographic boundary that by default, is set up around your installation address. This feature allows you to create location-based alerts and rules based on the location of one or more phones (Geo-Devices). A Geo-Fence can only be deleted using the GoSafer Security customer portal (powered by Alarm.com).

For more information about what Geo-Fences are, see [What is a Geo-Fence?](#).

Important: Deleting a Geo-Fence also deletes any rules or notifications that are dependent on the Geo-Fence.

To delete a Geo-Fence using the Alarm.com app:

Note: The default Geo-Fence cannot be renamed or deleted.

1. Log in to the Alarm.com app.
2. Tap .
3. Tap **Places**.
4. In *Places*, tap the name of the Geo-Fence to be deleted.
5. Tap **Edit Place**.
6. Tap **Delete Place**.
7. Tap **Delete Place** when prompted to confirm that you want to delete the Geo-Fence.


To delete a Geo-Fence using the GoSafer Security customer portal (powered by Alarm.com):

Note: The default Geo-Fence cannot be renamed or deleted.

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click **Settings**.
3. Click **Places**.
4. In *Manage Places*, click the name of the Geo-Fence to be deleted.

5. Click **Delete**.

6. Click Ok when prompted to confirm that you want to delete the Geo-Fence.



Source and support

For GoSafer Security assistance, visit gosafersecurity.com.

Original

Alarm.com

reference:

https://answers.alarm.com/Customer/Website_and_App/Mobile_Features/Geo-Fences/What_is_a_Geo-Fence

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:03 UTC by Jerdenn Calag

Updated 2026-09-01 16:40:46 UTC by Jerdenn Calag