

What login permissions does a secondary user login need to use Alarm.com Places?

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

By default, Master Control and Full Control permissions have Alarm.com Places capability enabled.

Platform	General / Device
Content type	How-to / Configuration
Source last updated	2023-02-15

Procedure

For Custom permissions, the Notification Settings feature must be selected to enable Alarm.com Places capability.

Full Control allows the user to enable Alarm.com Places and also make changes to the account's notifications.

Read Only allows the user to enable Alarm.com Places on their app, but they are not able to make changes to notifications.

For Read Only or Limited Device Access permissions, the user is able to view Alarm.com Places but is not capable of enabling it on their mobile device.

For more information about how to configure permissions for a secondary user, see Manage login permissions for secondary logins.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Mobile_Features/Geo-Devices/What_login_permissions_does_a_secondary_user_login_need_to_use_Geo-Services

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:03 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:03 UTC by Jerdenn Calag