

Configure the local display password for an Alarm.com Stream Video Recorder

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Set the local display password for an Alarm.com Stream Video Recorder (SVR) using the GoSafer Security customer portal (powered by Alarm.com).

Platform	Customer Website
Content type	How-to / Configuration
Source last updated	2025-12-08

Procedure

To configure the local display password

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Video.
3. Click Settings.
4. Select the desired SVR.

In Device Management, click Local Display.

In Local Device Password, enter the updated password.

1. Click Save.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
[https://answers.alarm.com/Customer/Website_and_App/Video/Video_Settings/Configure the local display_password_for_the_ADC-SVR210](https://answers.alarm.com/Customer/Website_and_App/Video/Video_Settings/Configure_the_local_display_password_for_the_ADC-SVR210)

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:17 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:17 UTC by Jerdenn Calag