

Enable or disable remote commands for lights or switches

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Remote commands for lights and switches are automatically enabled when enrolled, but can be disabled.

Platform	App + Web
Content type	How-to / Configuration
Source last updated	2025-10-14

Procedure

To enable/disable remote commands using the Alarm.com app

1. Log in to the Alarm.com app.
2. Tap [Menu].
3. Tap Manage Devices.

In Lights and Switches, tap [More Options] for the desired device to manage.

1. Tap Device Settings.

In Settings, tap Remote Commands Enabled to toggle on or off.

1. Tap Save.

To enable/disable remote commands using the GoSafer Security customer portal (powered by Alarm.com)

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Settings.
3. Click Manage Devices.

In Lights and Switches, click [More Options] for the desired device to manage.

1. Click Device Settings.

In Settings, click Remote Commands Enabled to toggle on or off.

1. Click Save.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original	Alarm.com	reference:
https://answers.alarm.com/Customer/Website_and_App/Home_Automation/Lights/Enable_or_disable_remote_commands_for_lights_or_switches		

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

