

Protect a video clip

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Video clips can be protected from automatic, manual, or accidental deletion.

Platform	Mobile App
Content type	Reference
Source last updated	2025-06-04

Procedure

On Android OS devices

1. Log in to the Alarm.com app.
2. Tap [Video].
3. Tap Saved.

Long press on a clip to select it.

To select multiple clips for bulk actions, tap [Grey Circle Checkmark], then tap to select the desired clips.

1. Tap [Options].
2. Tap Protect.

On iOS devices

1. Log in to the Alarm.com app.
2. Tap [Video].
3. Tap Saved.

Long press on a clip to select it.

To select multiple clips for bulk actions, tap Select, then tap to select the desired clips.

1. Tap [Lock].

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Video/Saved_Video/Protect_a_video_clip

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:15 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:15 UTC by Jerdenn Calag