

Remotely change 2GIG GoControl panel settings

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Change some of your panel settings using the app including beeps, chimes, and temperature display format.

Platform	Mobile App
Content type	How-to / Configuration
Source last updated	2025-06-04

Procedure

To change panel settings

1. Log in to the Alarm.com app.
2. Tap Security System.
3. Tap [Settings].
4. Tap the setting to be configured.
5. Tap the desired value.
6. Tap Save.

Compatible panel settings

Setting

Description

Silence Trouble Beeps at Night

If this feature is enabled then trouble conditions such as AC loss system low battery RF low battery fail to communicate cell radio faults will not be audible between the hour of 10 pm and 9 am. For UL 985 installations, this feature must be disabled.

Temperature Display

1. Select if the temperature is displayed in Fahrenheit or Celsius

Closing Acknowledgement Sound

1. Enable or disable the sound for an arming acknowledgment at the end of the exit delay

Data and Time Format

1. Select the format date and time format

Source and support

For GoSafer Security assistance, visit gosafersupport.com.

Original

Alarm.com

reference:

https://answers.alarm.com/Customer/Website_and_App/System_Management/System_Usage/Remotely_change_2GIG_GoControl_panel_settings

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:07 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:07 UTC by Jerdenn Calag