

Remotely change Interlogix Simon XT panel settings

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Change some of your panel settings using the app including beeps, chimes, and speaker volume.

Platform	Mobile App
Content type	Troubleshooting
Source last updated	2025-06-04

Procedure

To change settings using the Alarm.com app

1. Log in to the Alarm.com app.
2. Tap Security System.
3. Tap [Settings].
4. Tap the setting to be edited.
5. Tap the desired value.

6. Tap Save.

Compatible panel settings

Setting name

Setting options

Description

Sounds Settings

Piezo Beeps

Determines whether the panel piezo produces beeps based on system activity

Sounds Settings

Chime Voice

Determines whether the panel announces the sensor name

Sound Settings

Chime Type

Determines the type of chime for the sensors that chime (i.e., voice, bell, soft bell, off)

Sound Settings

Speaker Volume

Determines the volume of voice messages from the panel speaker

Sound Settings

Status Beep Volume

Determines the panel piezo volume level for status sounds such as arming, trouble, and status beeps

Sound Settings

System Status Announcement

Determines whether the panel announces arming level changes

Sound Settings

Panel Piezo Alarm

Determines whether the panel piezo siren turns on for alarms

Trouble Beeps

Trouble Beeps

1. Turns on/off the beeps issued by the security system when there is an active trouble

24 Hour Clock

24 Hour Clock

Determines whether the system uses a 24 hour clock (enable) or a 12 hour clock (disable)

Source and support

For GoSafer Security assistance, visit gosafersecurity.com.

Original

Alarm.com

reference:

https://answers.alarm.com/Customer/Website_and_App/System_Management/System_Usage/Remotely_change_Interlogix_Simon_XT_panel_settings

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:08 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:08 UTC by Jerdenn Calag