

Turn a Thermostat Schedule on/off

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Once configured, Thermostat Schedules can be turned on or off from the app and website.

Platform	App + Web
Content type	Reference
Source last updated	2025-06-04

Procedure

To turn a Thermostat Schedule on or off using the Alarm.com app

1. Log in to the Alarm.com app.
2. Tap Thermostats.
3. Tap Schedule [Schedule].
4. Tap Off or On.
5. Tap Set.

To turn a Thermostat Schedule on or off using the GoSafer Security customer portal (powered by Alarm.com)

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).

In the Thermostat card, click [Schedule].

1. Click Schedule On or Schedule Off.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original	Alarm.com	reference:
https://answers.alarm.com/Customer/Website_and_App/Home_Automation/Thermostats/Turn_a_Thermostat_Schedule_on_or_off		

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:01 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:01 UTC by Jerdenn Calag