

Edit a Wellness sensor name

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Wellness sensor names can be edited for easier system management.

Platform	Customer Website
Content type	How-to / Configuration
Source last updated	2025-06-04

Procedure

To edit a wellness sensor name

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).

On the Sensors card, click [Details].

In Sensor Name, enter the new sensor name for the sensor to update.

1. Click Save.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original

Alarm.com

reference:

[https://answers.alarm.com/Customer/Website_and_App/Wellness/Wellness_Management/Edit a Wellness_sensor_name](https://answers.alarm.com/Customer/Website_and_App/Wellness/Wellness_Management/Edit_a_Wellness_sensor_name)

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:18 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:19 UTC by Jerdenn Calag