

View the Wellness activity report

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Wellness activity reports help users understand room and sensor activity.

Platform	App + Web
Content type	Reference
Source last updated	2025-06-04

Procedure

To view the wellness activity report using the Alarm.com app

1. Log in to the Alarm.com app.
2. Tap Wellness.
3. Tap Daily Sensor Activity.

View activity based on sensor or room.

1. Tap Sensor to view daily sensor activity on an individual sensor level.

2. Tap Room to view the daily sensor activity on a room-by-room basis.

To view the wellness activity report using the GoSafer Security customer portal (powered by Alarm.com)

1. Log in to the GoSafer Security customer portal (powered by Alarm.com).
2. Click Activity.
3. Click Wellness.

Using the Select a View dropdown menu, select either

Activity by Sensor to show activity by the specific sensor name.

Activity by Room to show activity by sensors assigned to specific rooms.

Source and support

For GoSafer Security assistance, visit gosaferssecurity.com.

Original Alarm.com reference:
https://answers.alarm.com/Customer/Website_and_App/Wellness/Wellness_Management/View_the_Wellness_activity_report

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:19 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:19 UTC by Jerdenn Calag