

Not Networked Trouble

GoSafer Security Knowledge Base

This operational reference is organized for GoSafer Security customers and staff. Alarm.com product names are retained where required for technical accuracy.

Overview

Not Networked Trouble indicates that a device (usually a door/window contact sensor or a motion sensor) is out of sync with the wireless network or was not synchronized with the network after it was enrolled into your security panel.

Platform	General / Device
Content type	How-to / Configuration
Source last updated	2023-11-20

Procedure

How to resolve

Contact your service provider for assistance.

Source and support

For GoSafer Security assistance, visit [gosaferssecurity.com](https://answers.alarm.com).

Original

Alarm.com

reference:

https://answers.alarm.com/Customer/Website_and_App/System_Management/Trouble_Condition_H

[elp/Not Networked Trouble](#)

Always verify safety, installation, compatibility, and current UI details against the original manufacturer documentation before operational use.

Revision #1

Created 2026-09-01 00:30:09 UTC by Jerdenn Calag

Updated 2026-09-01 00:30:09 UTC by Jerdenn Calag